

# 3D Printer User Manual

## ProtoLab PRO-882

Printer Type: DLP

Target User: Professional

### 1. Safety Instructions

Always operate your 3D printer in a well-ventilated area. Avoid touching heated parts during or after printing. Keep the printer out of reach of children. Follow all setup procedures as described.

### 2. Setup & Assembly

This printer comes as: Semi-kit. Assembly typically takes 15-60 minutes. Ensure all components are included in the box. Use a level surface and connect power only after full assembly.

### 3. Printing Guide

Use supported slicers like Chitubox. Load filament/resin type: PLA, ABS, TPU. Recommended layer height: 0.24 - 0.48 mm. Print via: Wi-Fi, USB.

### 4. Maintenance & Care

Clean the nozzle regularly, keep the bed level, and ensure firmware is up to date. For resin printers, clean the vat after each print.

### 5. Technical Specifications

Build Volume: 207x250x382 mm

Nozzle Diameter: 0.2 mm

Max Print Speed: 127 mm/s

Heated Bed: No (Max Temp: N/A)

# 3D Printer User Manual

Firmware: Klipper

Certifications: RoHS, FCC

Warranty: 3 years